



- Products → Drives → Drive options → I/O options
- Parts & Services → Drives → Low voltage AC drives → Industrial drives → ACS880 drive modules → ACS880-04 - Single drive module
- Parts & Services → Drives → Low voltage AC drives → Industrial drives → ACS880 drive modules → ACS880-04F
- Parts & Services → Drives → Low voltage AC drives → Industrial drives → ACS880 multidrives → ACS880-107 - Inverter unit
- Parts & Services → Drives → Low voltage AC drives → Industrial drives → ACS880 single drives → ACS880-01 - Wall-mounted single drive
- Parts & Services → Drives → Low voltage AC drives → Industrial drives → ACS880 single drives → ACS880-07 - Cabinet-built single drive
- Parts & Services → Drives → Low voltage AC drives → Industrial drives → ACS880 single drives → ACS880-17 - Cabinet-built regenerative single drive
- Parts & Services → Drives → Low voltage AC drives → Industrial drives → ACS880 single drives → ACS880-37 - Cabinet-built low harmonic single drive
- Parts & Services → Drives → Low voltage AC drives → Industry-specific drives → Drives for elevators → ACSM1-04xL - elevator drive module
- Parts & Services → Drives → Low voltage AC drives → Machinery drives → ACS850-04 - Machinery Drive Module
- Parts & Services → Drives → Low voltage AC drives → Machinery drives → ACS880-M04 - Machinery Drive
- Parts & Services → Drives → Low voltage AC drives → Machinery drives → ACSM1-04 - Machinery Drive Module

General Information

Product ID:	68805848
ABB Type Designation:	FEN-21
Catalog Description:	FEN-21; Resolver Interface FEN-21

Ordering

Core Credit:	0.00
Country of Origin:	Finland (FI) China (CN)
Customs Tariff Number:	85049099
Invoice Description:	Resolver Interface FEN-21
Made To Order:	Yes
Minimum Order Quantity:	1 piece
Order Multiple:	1 piece
Quote Only:	No
Replaced Product ID (OLD):	68679303 68630738
Selling Unit of Measure:	piece
Stocked At (Warehouses):	Central Stock US FIPSEEXPU SGRDC002EXPU CNIAB001EXPU SGIND002EXPU AUABB024EXPU

Additional Information

Product Main Type:	FEN-21
Product Name:	Resolver Interface

Where Used (as a spare part for "Products")

Identifier	Description	Qty	Unit Of Measure
ACS850-04-010A-2	No Description Available	1	piece

ACS850-04-010A-2 Identifier	No Description Available Description	1 Qty	piece Unit Of Measure
ACS850-04-010A-5	No Description Available	1	piece
ACS850-04-014A-2	No Description Available	1	piece
ACS850-04-014A-5	No Description Available	1	piece
ACS850-04-018A-2	No Description Available	1	piece
ACS850-04-018A-5	No Description Available	1	piece
ACS850-04-025A-2	No Description Available	1	piece
ACS850-04-025A-5	No Description Available	1	piece
ACS850-04-030A-2	No Description Available	1	piece
ACS850-04-030A-5	No Description Available	1	piece
ACS850-04-035A-2	No Description Available	1	piece
ACS850-04-035A-5	No Description Available	1	piece
ACS850-04-03A0-2	No Description Available	1	piece
ACS850-04-03A0-5	No Description Available	1	piece
ACS850-04-03A6-2	No Description Available	1	piece
ACS850-04-03A6-5	No Description Available	1	piece
ACS850-04-044A-2	No Description Available	1	piece
ACS850-04-044A-5	No Description Available	1	piece
ACS850-04-04A8-2	No Description Available	1	piece
ACS850-04-04A8-5	No Description Available	1	piece
ACS850-04-050A-2	No Description Available	1	piece
ACS850-04-050A-5	No Description Available	1	piece
ACS850-04-061A-2	No Description Available	1	piece
ACS850-04-061A-5	No Description Available	1	piece
ACS850-04-06A0-2	No Description Available	1	piece
ACS850-04-06A0-5	No Description Available	1	piece
ACS850-04-078A-2	No Description Available	1	piece
ACS850-04-078A-5	No Description Available	1	piece
ACS850-04-08A0-2	No Description Available	1	piece
ACS850-04-08A0-5	No Description Available	1	piece
ACS850-04-094A-2	No Description Available	1	piece
ACS850-04-094A-5	No Description Available	1	piece
ACS850-04-103A-5	No Description Available	1	piece
ACS850-04-144A-5	No Description Available	1	piece
ACS850-04-166A-5	No Description Available	1	piece
ACS850-04-202A-5	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS850-04-225A-5	No Description Available	1	piece
ACS850-04-260A-5	No Description Available	1	piece
ACS850-04-290A-5	No Description Available	1	piece
ACS850-04-387A-5	No Description Available	1	piece
ACS850-04-430A-5	No Description Available	1	piece
ACS850-04-500A-5	No Description Available	1	piece
ACS850-04-521A-5	No Description Available	1	piece
ACS850-04-580A-5	No Description Available	1	piece
ACS850-04-602A-5	No Description Available	1	piece
ACS850-04-650A-5	No Description Available	1	piece
ACS850-04-693A-5	No Description Available	1	piece
ACS850-04-710A-5	No Description Available	1	piece
ACS850-04-720A-5	No Description Available	1	piece
ACS850-04-807A-5	No Description Available	1	piece
ACS850-04-875A-5	No Description Available	1	piece
ACS850-04-DEMOCASE-	No Description Available	1	piece
ACS880-01-010A-7	No Description Available	1	piece
ACS880-01-013A-4	No Description Available	1	piece
ACS880-01-014A-5	No Description Available	1	piece
ACS880-01-017A-3	No Description Available	1	piece
ACS880-01-018A-7	No Description Available	1	piece
ACS880-01-019A-4	No Description Available	1	piece
ACS880-01-019A-7	No Description Available	1	piece
ACS880-01-021A-5	No Description Available	1	piece
ACS880-01-022A-7	No Description Available	1	piece
ACS880-01-023A-7	No Description Available	1	piece
ACS880-01-025A-3	No Description Available	1	piece
ACS880-01-026A-4	No Description Available	1	piece
ACS880-01-026A-7	No Description Available	1	piece
ACS880-01-027A-5	No Description Available	1	piece
ACS880-01-027A-7	No Description Available	1	piece
ACS880-01-02A0-4	No Description Available	1	piece
ACS880-01-02A1-5	No Description Available	1	piece
ACS880-01-02A4-3	No Description Available	1	piece
ACS880-01-02A8-4	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS880-01-031A-2	No Description Available	1	piece
ACS880-01-032A-3	No Description Available	1	piece
ACS880-01-032A-4	No Description Available	1	piece
ACS880-01-034A-5	No Description Available	1	piece
ACS880-01-035A-3	No Description Available	1	piece
ACS880-01-035A-7	No Description Available	1	piece
ACS880-01-038A-3	No Description Available	1	piece
ACS880-01-038A-4	No Description Available	1	piece
ACS880-01-03A0-3	No Description Available	1	piece
ACS880-01-03A0-5	No Description Available	1	piece
ACS880-01-03A2-4	No Description Available	1	piece
ACS880-01-03A3-3	No Description Available	1	piece
ACS880-01-03A4-5	No Description Available	1	piece
ACS880-01-03A9-3	No Description Available	1	piece
ACS880-01-040A-5	No Description Available	1	piece
ACS880-01-042A-7	No Description Available	1	piece
ACS880-01-043A-3	No Description Available	1	piece
ACS880-01-045A-3	No Description Available	1	piece
ACS880-01-046A-2	No Description Available	1	piece
ACS880-01-049A-4	No Description Available	1	piece
ACS880-01-049A-7	No Description Available	1	piece
ACS880-01-04A0-3	No Description Available	1	piece
ACS880-01-04A6-2	No Description Available	1	piece
ACS880-01-04A6-4	No Description Available	1	piece
ACS880-01-04A8-5	No Description Available	1	piece
ACS880-01-04A9-4	No Description Available	1	piece
ACS880-01-050A-3	No Description Available	1	piece
ACS880-01-052A-5	No Description Available	1	piece
ACS880-01-05A2-5	No Description Available	1	piece
ACS880-01-05A6-3	No Description Available	1	piece
ACS880-01-05A8-3	No Description Available	1	piece
ACS880-01-060A-7	No Description Available	1	piece
ACS880-01-061A-2	No Description Available	1	piece
ACS880-01-061A-3	No Description Available	1	piece
ACS880-01-061A-7	No Description Available	1	piece
ACS880-01-062A-4	No Description Available	1	piece

ACS880-01-062A-4 Identifier	No Description Available Description	1 Qty	piece Unit Of Measure
ACS880-01-065A-5	No Description Available	1	piece
ACS880-01-069A-3	No Description Available	1	piece
ACS880-01-06A6-2	No Description Available	1	piece
ACS880-01-071A-7	No Description Available	1	piece
ACS880-01-072A-3	No Description Available	1	piece
ACS880-01-073A-4	No Description Available	1	piece
ACS880-01-075A-2	No Description Available	1	piece
ACS880-01-077A-5	No Description Available	1	piece
ACS880-01-07A2-3	No Description Available	1	piece
ACS880-01-07A2-4	No Description Available	1	piece
ACS880-01-07A3-7	No Description Available	1	piece
ACS880-01-07A4-7	No Description Available	1	piece
ACS880-01-07A5-2	No Description Available	1	piece
ACS880-01-07A5-3	No Description Available	1	piece
ACS880-01-07A6-5	No Description Available	1	piece
ACS880-01-084A-7	No Description Available	1	piece
ACS880-01-085A-3	No Description Available	1	piece
ACS880-01-087A-2	No Description Available	1	piece
ACS880-01-087A-3	No Description Available	1	piece
ACS880-01-091A-4	No Description Available	1	piece
ACS880-01-096A-5	No Description Available	1	piece
ACS880-01-098A-7	No Description Available	1	piece
ACS880-01-09A4-3	No Description Available	1	piece
ACS880-01-09A8-3	No Description Available	1	piece
ACS880-01-09A8-7	No Description Available	1	piece
ACS880-01-09A9-7	No Description Available	1	piece
ACS880-01-100A-7	No Description Available	1	piece
ACS880-01-103A-3	No Description Available	1	piece
ACS880-01-105A-3	No Description Available	1	piece
ACS880-01-10A4-4	No Description Available	1	piece
ACS880-01-10A6-2	No Description Available	1	piece
ACS880-01-115A-2	No Description Available	1	piece
ACS880-01-117A-7	No Description Available	1	piece
ACS880-01-118A-4	No Description Available	1	piece
ACS880-01-119A-7	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS880-01-11A0-5	No Description Available	1	piece
ACS880-01-123A-3	No Description Available	1	piece
ACS880-01-124A-5	No Description Available	1	piece
ACS880-01-12A6-3	No Description Available	1	piece
ACS880-01-13A4-3	No Description Available	1	piece
ACS880-01-142A-7	No Description Available	1	piece
ACS880-01-143A-7	No Description Available	1	piece
ACS880-01-145A-2	No Description Available	1	piece
ACS880-01-145A-3	No Description Available	1	piece
ACS880-01-148A-4	No Description Available	1	piece
ACS880-01-14A2-7	No Description Available	1	piece
ACS880-01-14A3-3	No Description Available	1	piece
ACS880-01-14A3-7	No Description Available	1	piece
ACS880-01-14A5-7	No Description Available	1	piece
ACS880-01-156A-5	No Description Available	1	piece
ACS880-01-168A-7	No Description Available	1	piece
ACS880-01-169A-3	No Description Available	1	piece
ACS880-01-16A8-2	No Description Available	1	piece
ACS880-01-170A-2	No Description Available	1	piece
ACS880-01-171A-4	No Description Available	1	piece
ACS880-01-173A-3	No Description Available	1	piece
ACS880-01-174A-7	No Description Available	1	piece
ACS880-01-17A5-3	No Description Available	1	piece
ACS880-01-17A7-3	No Description Available	1	piece
ACS880-01-180A-5	No Description Available	1	piece
ACS880-01-199A-7	No Description Available	1	piece
ACS880-01-202A-3	No Description Available	1	piece
ACS880-01-206A-2	No Description Available	1	piece
ACS880-01-206A-3	No Description Available	1	piece
ACS880-01-20A2-7	No Description Available	1	piece
ACS880-01-210A-7	No Description Available	1	piece
ACS880-01-228A-4	No Description Available	1	piece
ACS880-01-240A-5	No Description Available	1	piece
ACS880-01-245A-3	No Description Available	1	piece
ACS880-01-246A-3	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS880-01-247A-4	No Description Available	1	piece
ACS880-01-248A-7	No Description Available	1	piece
ACS880-01-24A3-2	No Description Available	1	piece
ACS880-01-24A8-7	No Description Available	1	piece
ACS880-01-25A1-3	No Description Available	1	piece
ACS880-01-25A5-3	No Description Available	1	piece
ACS880-01-260A-5	No Description Available	1	piece
ACS880-01-271A-7	No Description Available	1	piece
ACS880-01-274A-2	No Description Available	1	piece
ACS880-01-290A-3	No Description Available	1	piece
ACS880-01-293A-3	No Description Available	1	piece
ACS880-01-29A0-7	No Description Available	1	piece
ACS880-01-303A-5	No Description Available	1	piece
ACS880-01-343A-3	No Description Available	1	piece
ACS880-01-343A-4	No Description Available	1	piece
ACS880-01-361A-5	No Description Available	1	piece
ACS880-01-362A-5	No Description Available	1	piece
ACS880-01-363A-3	No Description Available	1	piece
ACS880-01-364A-3	No Description Available	1	piece
ACS880-01-393A-4	No Description Available	1	piece
ACS880-01-39A9-7	No Description Available	1	piece
ACS880-01-414A-5	No Description Available	1	piece
ACS880-01-415A-5	No Description Available	1	piece
ACS880-01-427A-3	No Description Available	1	piece
ACS880-01-428A-3	No Description Available	1	piece
ACS880-01-430A-3	No Description Available	1	piece
ACS880-01-441A-5	No Description Available	1	piece
ACS880-01-442A-3	No Description Available	1	piece
ACS880-01-47A5-7	No Description Available	1	piece
ACS880-04-330A-7	No Description Available	1	piece
ACS880-04-370A-7	No Description Available	1	piece
ACS880-04-425A-7	No Description Available	1	piece
ACS880-04-430A-7	No Description Available	1	piece
ACS880-04-460A-5	No Description Available	1	piece
ACS880-04-470A-7	No Description Available	1	piece
ACS880-04-503A-5	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS880-04-505A-3	No Description Available	1	piece
ACS880-04-522A-7	No Description Available	1	piece
ACS880-04-583A-5	No Description Available	1	piece
ACS880-04-585A-3	No Description Available	1	piece
ACS880-04-590A-7	No Description Available	1	piece
ACS880-04-635A-5	No Description Available	1	piece
ACS880-04-650A-3	No Description Available	1	piece
ACS880-04-650A-7	No Description Available	1	piece
ACS880-04-715A-5	No Description Available	1	piece
ACS880-04-721A-7	No Description Available	1	piece
ACS880-04-725A-3	No Description Available	1	piece
ACS880-04-820A-3	No Description Available	1	piece
ACS880-04-820A-5	No Description Available	1	piece
ACS880-04-880A-3	No Description Available	1	piece
ACS880-04-880A-5	No Description Available	1	piece
ACS880-04F-329A-7	No Description Available	1	piece
ACS880-04F-369A-7	No Description Available	1	piece
ACS880-04F-429A-7	No Description Available	1	piece
ACS880-04F-459A-5	No Description Available	1	piece
ACS880-04F-470A-7	No Description Available	1	piece
ACS880-04F-502A-5	No Description Available	1	piece
ACS880-04F-504A-3	No Description Available	1	piece
ACS880-04F-522A-7	No Description Available	1	piece
ACS880-04F-582A-5	No Description Available	1	piece
ACS880-04F-584A-3	No Description Available	1	piece
ACS880-04F-590A-7	No Description Available	1	piece
ACS880-04F-634A-5	No Description Available	1	piece
ACS880-04F-649A-3	No Description Available	1	piece
ACS880-04F-650A-7	No Description Available	1	piece
ACS880-04F-715A-5	No Description Available	1	piece
ACS880-04F-721A-7	No Description Available	1	piece
ACS880-04F-725A-3	No Description Available	1	piece
ACS880-04F-820A-3	No Description Available	1	piece
ACS880-04F-820A-5	No Description Available	1	piece
ACS880-04F-880A-3	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS880-04F-880A-5	No Description Available	1	piece
ACS880-07-0061A-7	No Description Available	1	piece
ACS880-07-0084A-7	No Description Available	1	piece
ACS880-07-0096A-5	No Description Available	1	piece
ACS880-07-0098A-7	No Description Available	1	piece
ACS880-07-0105A-3	No Description Available	1	piece
ACS880-07-0119A-7	No Description Available	1	piece
ACS880-07-0124A-5	No Description Available	1	piece
ACS880-07-0142A-7	No Description Available	1	piece
ACS880-07-0145A-3	No Description Available	1	piece
ACS880-07-0156A-5	No Description Available	1	piece
ACS880-07-0169A-3	No Description Available	1	piece
ACS880-07-0174A-7	No Description Available	1	piece
ACS880-07-0180A-5	No Description Available	1	piece
ACS880-07-0206A-3	No Description Available	1	piece
ACS880-07-0210A-7	No Description Available	1	piece
ACS880-07-0240A-5	No Description Available	1	piece
ACS880-07-0246A-3	No Description Available	1	piece
ACS880-07-0260A-5	No Description Available	1	piece
ACS880-07-0271A-7	No Description Available	1	piece
ACS880-07-0293A-3	No Description Available	1	piece
ACS880-07-0302A-5	No Description Available	1	piece
ACS880-07-0330A-7	No Description Available	1	piece
ACS880-07-0361A-5	No Description Available	1	piece
ACS880-07-0363A-3	No Description Available	1	piece
ACS880-07-0370A-7	No Description Available	1	piece
ACS880-07-0414A-5	No Description Available	1	piece
ACS880-07-0425A-7	No Description Available	1	piece
ACS880-07-0430A-3	No Description Available	1	piece
ACS880-07-0430A-7	No Description Available	1	piece
ACS880-07-0460A-5	No Description Available	1	piece
ACS880-07-0470A-7	No Description Available	1	piece
ACS880-07-0503A-5	No Description Available	1	piece
ACS880-07-0505A-3	No Description Available	1	piece
ACS880-07-0522A-7	No Description Available	1	piece

ACS880-07-0583A-5 Identifier	No Description Available Description	1 Qty	piece Unit Of Measure
ACS880-07-0585A-3	No Description Available	1	piece
ACS880-07-0590A-7	No Description Available	1	piece
ACS880-07-0635A-5	No Description Available	1	piece
ACS880-07-0650A-3	No Description Available	1	piece
ACS880-07-0650A-7	No Description Available	1	piece
ACS880-07-0715A-5	No Description Available	1	piece
ACS880-07-0721A-7	No Description Available	1	piece
ACS880-07-0725A-3	No Description Available	1	piece
ACS880-07-0800A-7	No Description Available	1	piece
ACS880-07-0820A-3	No Description Available	1	piece
ACS880-07-0820A-5	No Description Available	1	piece
ACS880-07-0880A-3	No Description Available	1	piece
ACS880-07-0880A-5	No Description Available	1	piece
ACS880-07-0900A-7	No Description Available	1	piece
ACS880-07-0950A-7	No Description Available	1	piece
ACS880-07-0990A-3	No Description Available	1	piece
ACS880-07-0990A-5	No Description Available	1	piece
ACS880-07-1070A-5	No Description Available	1	piece
ACS880-07-1140A-3	No Description Available	1	piece
ACS880-07-1160A-7	No Description Available	1	piece
ACS880-07-1250A-3	No Description Available	1	piece
ACS880-07-1320A-5	No Description Available	1	piece
ACS880-07-1450A-5	No Description Available	1	piece
ACS880-07-1450A-7	No Description Available	1	piece
ACS880-07-1480A-3	No Description Available	1	piece
ACS880-07-1580A-5	No Description Available	1	piece
ACS880-07-1650A-7	No Description Available	1	piece
ACS880-07-1760A-3	No Description Available	1	piece
ACS880-07-1800A-5	No Description Available	1	piece
ACS880-07-1950A-7	No Description Available	1	piece
ACS880-07-1980A-5	No Description Available	1	piece
ACS880-07-2210A-3	No Description Available	1	piece
ACS880-07-2300A-7	No Description Available	1	piece
ACS880-07-2600A-7	No Description Available	1	piece
ACS880-07-2610A-3	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS880-07-2860A-7	No Description Available	1	piece
ACS880-107-0011A-3	No Description Available	1	piece
ACS880-107-0011A-5	No Description Available	1	piece
ACS880-107-0014A-3	No Description Available	1	piece
ACS880-107-0014A-5	No Description Available	1	piece
ACS880-107-0018A-3	No Description Available	1	piece
ACS880-107-0018A-5	No Description Available	1	piece
ACS880-107-0018A-7	No Description Available	1	piece
ACS880-107-0022A-7	No Description Available	1	piece
ACS880-107-0025A-3	No Description Available	1	piece
ACS880-107-0025A-5	No Description Available	1	piece
ACS880-107-0027A-7	No Description Available	1	piece
ACS880-107-0030A-5	No Description Available	1	piece
ACS880-107-0035A-3	No Description Available	1	piece
ACS880-107-0035A-5	No Description Available	1	piece
ACS880-107-0035A-7	No Description Available	1	piece
ACS880-107-003A6-5	No Description Available	1	piece
ACS880-107-0042A-7	No Description Available	1	piece
ACS880-107-0044A-3	No Description Available	1	piece
ACS880-107-004A8-3	No Description Available	1	piece
ACS880-107-004A8-5	No Description Available	1	piece
ACS880-107-0050A-3	No Description Available	1	piece
ACS880-107-0050A-5	No Description Available	1	piece
ACS880-107-0052A-7	No Description Available	1	piece
ACS880-107-0061A-3	No Description Available	1	piece
ACS880-107-0061A-5	No Description Available	1	piece
ACS880-107-0062A-7	No Description Available	1	piece
ACS880-107-006A0-3	No Description Available	1	piece
ACS880-107-006A0-5	No Description Available	1	piece
ACS880-107-0078A-3	No Description Available	1	piece
ACS880-107-0078A-5	No Description Available	1	piece
ACS880-107-007A3-7	No Description Available	1	piece
ACS880-107-0082A-7	No Description Available	1	piece
ACS880-107-008A0-3	No Description Available	1	piece
ACS880-107-008A0-5	No Description Available	1	piece

Part Number	Description	Qty	Unit Of Measure
ACS880-107-0094A-3	No Description Available		
ACS880-107-0094A-5	No Description Available	1	piece
ACS880-107-009A8-7	No Description Available	1	piece
ACS880-107-0100A-3	No Description Available	1	piece
ACS880-107-0100A-7	No Description Available	1	piece
ACS880-107-0110A-5	No Description Available	1	piece
ACS880-107-0130A-7	No Description Available	1	piece
ACS880-107-0140A-3	No Description Available	1	piece
ACS880-107-0140A-5	No Description Available	1	piece
ACS880-107-0140A-7	No Description Available	1	piece
ACS880-107-014A2-7	No Description Available	1	piece
ACS880-107-0170A-3	No Description Available	1	piece
ACS880-107-0170A-5	No Description Available	1	piece
ACS880-107-0190A-7	No Description Available	1	piece
ACS880-107-0200A-5	No Description Available	1	piece
ACS880-107-0210A-3	No Description Available	1	piece
ACS880-107-0220A-7	No Description Available	1	piece
ACS880-107-0240A-5	No Description Available	1	piece
ACS880-107-0250A-3	No Description Available	1	piece
ACS880-107-0270A-7	No Description Available	1	piece
ACS880-107-0300A-3	No Description Available	1	piece
ACS880-107-0300A-5	No Description Available	1	piece
ACS880-107-0340A-5	No Description Available	1	piece
ACS880-107-0340A-7	No Description Available	1	piece
ACS880-107-0350A-3	No Description Available	1	piece
ACS880-107-0410A-7	No Description Available	1	piece
ACS880-107-0440A-5	No Description Available	1	piece
ACS880-107-0470A-3	No Description Available	1	piece
ACS880-107-0530A-7	No Description Available	1	piece
ACS880-107-0590A-5	No Description Available	1	piece
ACS880-107-0600A-7	No Description Available	1	piece
ACS880-107-0640A-3	No Description Available	1	piece
ACS880-107-0740A-5	No Description Available	1	piece
ACS880-107-0760A-3	No Description Available	1	piece
ACS880-107-0800A-7	No Description Available	1	piece

ACS880-107-0810A-5 Identifier	No Description Available Description	1 Qty	piece Unit Of Measure
ACS880-107-0900A-3	No Description Available	1	piece
ACS880-107-1030A-7	No Description Available	1	piece
ACS880-107-1150A-5	No Description Available	1	piece
ACS880-107-1170A-7	No Description Available	1	piece
ACS880-107-1250A-3	No Description Available	1	piece
ACS880-107-1450A-5	No Description Available	1	piece
ACS880-107-1480A-3	No Description Available	1	piece
ACS880-107-1540A-7	No Description Available	1	piece
ACS880-107-1580A-5	No Description Available	1	piece
ACS880-107-1740A-7	No Description Available	1	piece
ACS880-107-1760A-3	No Description Available	1	piece
ACS880-107-2150A-5	No Description Available	1	piece
ACS880-107-2210A-3	No Description Available	1	piece
ACS880-107-2300A-7	No Description Available	1	piece
ACS880-107-2350A-5	No Description Available	1	piece
ACS880-107-2610A-3	No Description Available	1	piece
ACS880-107-2860A-7	No Description Available	1	piece
ACS880-107-3110A-5	No Description Available	1	piece
ACS880-107-3420A-7	No Description Available	1	piece
ACS880-107-3450A-3	No Description Available	1	piece
ACS880-107-3860A-5	No Description Available	1	piece
ACS880-107-3990A-7	No Description Available	1	piece
ACS880-107-4290A-3	No Description Available	1	piece
ACS880-107-4560A-7	No Description Available	1	piece
ACS880-107-4610A-5	No Description Available	1	piece
ACS880-107-5130A-3	No Description Available	1	piece
ACS880-107-5130A-7	No Description Available	1	piece
ACS880-107-5700A-7	No Description Available	1	piece
ACS880-17-0101A-5	No Description Available	1	piece
ACS880-17-0105A-3	No Description Available	1	piece
ACS880-17-0124A-5	No Description Available	1	piece
ACS880-17-0145A-3	No Description Available	1	piece
ACS880-17-0156A-5	No Description Available	1	piece
ACS880-17-0169A-3	No Description Available	1	piece
ACS880-17-0174A-7	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS880-17-0180A-5	No Description Available	1	piece
ACS880-17-0206A-3	No Description Available	1	piece
ACS880-17-0210A-7	No Description Available	1	piece
ACS880-17-0260A-5	No Description Available	1	piece
ACS880-17-0271A-7	No Description Available	1	piece
ACS880-17-0293A-3	No Description Available	1	piece
ACS880-17-0302A-5	No Description Available	1	piece
ACS880-17-0320A-7	No Description Available	1	piece
ACS880-17-0330A-7	No Description Available	1	piece
ACS880-17-0361A-5	No Description Available	1	piece
ACS880-17-0363A-3	No Description Available	1	piece
ACS880-17-0370A-7	No Description Available	1	piece
ACS880-17-0390A-7	No Description Available	1	piece
ACS880-17-0414A-5	No Description Available	1	piece
ACS880-17-0420A-5	No Description Available	1	piece
ACS880-17-0430A-3	No Description Available	1	piece
ACS880-17-0430A-7	No Description Available	1	piece
ACS880-17-0442A-3	No Description Available	1	piece
ACS880-17-0450A-3	No Description Available	1	piece
ACS880-17-0460A-5	No Description Available	1	piece
ACS880-17-0503A-5	No Description Available	1	piece
ACS880-17-0505A-3	No Description Available	1	piece
ACS880-17-0570A-5	No Description Available	1	piece
ACS880-17-0580A-7	No Description Available	1	piece
ACS880-17-0583A-5	No Description Available	1	piece
ACS880-17-0585A-3	No Description Available	1	piece
ACS880-17-0620A-3	No Description Available	1	piece
ACS880-17-0650A-3	No Description Available	1	piece
ACS880-17-0660A-7	No Description Available	1	piece
ACS880-17-0770A-7	No Description Available	1	piece
ACS880-17-0780A-5	No Description Available	1	piece
ACS880-17-0870A-3	No Description Available	1	piece
ACS880-17-0950A-7	No Description Available	1	piece
ACS880-17-1010A-5	No Description Available	1	piece
ACS880-17-1110A-3	No Description Available	1	piece

Part Number	Description	Qty	Unit Of Measure
ACS880-17-1110A-5	No Description Available		
ACS880-17-1130A-7	No Description Available	1	piece
ACS880-17-1210A-3	No Description Available	1	piece
ACS880-17-1430A-3	No Description Available	1	piece
ACS880-17-1450A-7	No Description Available	1	piece
ACS880-17-1530A-5	No Description Available	1	piece
ACS880-17-1680A-7	No Description Available	1	piece
ACS880-17-1700A-3	No Description Available	1	piece
ACS880-17-1950A-7	No Description Available	1	piece
ACS880-17-1980A-5	No Description Available	1	piece
ACS880-17-2060A-3	No Description Available	1	piece
ACS880-17-2230A-7	No Description Available	1	piece
ACS880-17-2270A-5	No Description Available	1	piece
ACS880-17-2530A-3	No Description Available	1	piece
ACS880-17-2770A-7	No Description Available	1	piece
ACS880-17-3310A-7	No Description Available	1	piece
ACS880-37-0101A-5	No Description Available	1	piece
ACS880-37-0105A-3	No Description Available	1	piece
ACS880-37-0124A-5	No Description Available	1	piece
ACS880-37-0145A-3	No Description Available	1	piece
ACS880-37-0156A-5	No Description Available	1	piece
ACS880-37-0169A-3	No Description Available	1	piece
ACS880-37-0174A-7	No Description Available	1	piece
ACS880-37-0180A-5	No Description Available	1	piece
ACS880-37-0206A-3	No Description Available	1	piece
ACS880-37-0210A-7	No Description Available	1	piece
ACS880-37-0260A-5	No Description Available	1	piece
ACS880-37-0271A-7	No Description Available	1	piece
ACS880-37-0293A-3	No Description Available	1	piece
ACS880-37-0302A-5	No Description Available	1	piece
ACS880-37-0320A-7	No Description Available	1	piece
ACS880-37-0330A-7	No Description Available	1	piece
ACS880-37-0361A-5	No Description Available	1	piece
ACS880-37-0363A-3	No Description Available	1	piece
ACS880-37-0370A-7	No Description Available	1	piece

ACS880-37-0390A-7 Identifier	No Description Available Description	1 Qty	piece Unit Of Measure
ACS880-37-0414A-5	No Description Available	1	piece
ACS880-37-0420A-5	No Description Available	1	piece
ACS880-37-0430A-3	No Description Available	1	piece
ACS880-37-0430A-7	No Description Available	1	piece
ACS880-37-0442A-3	No Description Available	1	piece
ACS880-37-0450A-3	No Description Available	1	piece
ACS880-37-0460A-5	No Description Available	1	piece
ACS880-37-0503A-5	No Description Available	1	piece
ACS880-37-0505A-3	No Description Available	1	piece
ACS880-37-0570A-5	No Description Available	1	piece
ACS880-37-0580A-7	No Description Available	1	piece
ACS880-37-0583A-5	No Description Available	1	piece
ACS880-37-0585A-3	No Description Available	1	piece
ACS880-37-0620A-3	No Description Available	1	piece
ACS880-37-0650A-3	No Description Available	1	piece
ACS880-37-0660A-7	No Description Available	1	piece
ACS880-37-0770A-7	No Description Available	1	piece
ACS880-37-0780A-5	No Description Available	1	piece
ACS880-37-0870A-3	No Description Available	1	piece
ACS880-37-0950A-7	No Description Available	1	piece
ACS880-37-1010A-5	No Description Available	1	piece
ACS880-37-1110A-3	No Description Available	1	piece
ACS880-37-1110A-5	No Description Available	1	piece
ACS880-37-1130A-7	No Description Available	1	piece
ACS880-37-1210A-3	No Description Available	1	piece
ACS880-37-1430A-3	No Description Available	1	piece
ACS880-37-1450A-7	No Description Available	1	piece
ACS880-37-1530A-5	No Description Available	1	piece
ACS880-37-1680A-7	No Description Available	1	piece
ACS880-37-1700A-3	No Description Available	1	piece
ACS880-37-1950A-7	No Description Available	1	piece
ACS880-37-1980A-5	No Description Available	1	piece
ACS880-37-2060A-3	No Description Available	1	piece
ACS880-37-2230A-7	No Description Available	1	piece
ACS880-37-2270A-5	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACS880-37-2530A-3	No Description Available	1	piece
ACS880-37-2770A-7	No Description Available	1	piece
ACS880-37-3310A-7	No Description Available	1	piece
ACS880-M04-04-010A-2	No Description Available	1	piece
ACS880-M04-04-010A-5	No Description Available	1	piece
ACS880-M04-04-014A-2	No Description Available	1	piece
ACS880-M04-04-014A-5	No Description Available	1	piece
ACS880-M04-04-018A-2	No Description Available	1	piece
ACS880-M04-04-018A-5	No Description Available	1	piece
ACS880-M04-04-025A-2	No Description Available	1	piece
ACS880-M04-04-025A-5	No Description Available	1	piece
ACS880-M04-04-030A-2	No Description Available	1	piece
ACS880-M04-04-030A-5	No Description Available	1	piece
ACS880-M04-04-035A-2	No Description Available	1	piece
ACS880-M04-04-035A-5	No Description Available	1	piece
ACS880-M04-04-03A0-2	No Description Available	1	piece
ACS880-M04-04-03A0-5	No Description Available	1	piece
ACS880-M04-04-03A6-2	No Description Available	1	piece
ACS880-M04-04-03A6-5	No Description Available	1	piece
ACS880-M04-04-044A-2	No Description Available	1	piece
ACS880-M04-04-044A-5	No Description Available	1	piece
ACS880-M04-04-04A8-2	No Description Available	1	piece
ACS880-M04-04-04A8-5	No Description Available	1	piece
ACS880-M04-04-050A-2	No Description Available	1	piece
ACS880-M04-04-050A-5	No Description Available	1	piece
ACS880-M04-04-061A-2	No Description Available	1	piece
ACS880-M04-04-061A-5	No Description Available	1	piece
ACS880-M04-04-06A0-2	No Description Available	1	piece
ACS880-M04-04-06A0-5	No Description Available	1	piece
ACS880-M04-04-078A-2	No Description Available	1	piece
ACS880-M04-04-078A-5	No Description Available	1	piece
ACS880-M04-04-08A0-2	No Description Available	1	piece
ACS880-M04-04-08A0-5	No Description Available	1	piece
ACS880-M04-04-094A-2	No Description Available	1	piece
ACS880-M04-04-094A-5	No Description Available	1	piece

Item Number	Description	Qty	Unit Of Measure
ACSM1-04AL-012A-4	No Description Available		
ACSM1-04AL-016A-4	No Description Available	1	piece
ACSM1-04AL-024A-4	No Description Available	1	piece
ACSM1-04AL-02A5-4	No Description Available	1	piece
ACSM1-04AL-031A-4	No Description Available	1	piece
ACSM1-04AL-03A0-4	No Description Available	1	piece
ACSM1-04AL-040A-4	No Description Available	1	piece
ACSM1-04AL-046A-4	No Description Available	1	piece
ACSM1-04AL-04A0-4	No Description Available	1	piece
ACSM1-04AL-05A0-4	No Description Available	1	piece
ACSM1-04AL-060A-4	No Description Available	1	piece
ACSM1-04AL-073A-4	No Description Available	1	piece
ACSM1-04AL-07A0-4	No Description Available	1	piece
ACSM1-04AL-090A-4	No Description Available	1	piece
ACSM1-04AL-09A5-4	No Description Available	1	piece
ACSM1-04AL-110A-4	No Description Available	1	piece
ACSM1-04AL-135A-4	No Description Available	1	piece
ACSM1-04AL-175A-4	No Description Available	1	piece
ACSM1-04AL-210A-4	No Description Available	1	piece
ACSM1-04AM-012A-4	No Description Available	1	piece
ACSM1-04AM-016A-4	No Description Available	1	piece
ACSM1-04AM-024A-4	No Description Available	1	piece
ACSM1-04AM-02A5-4	No Description Available	1	piece
ACSM1-04AM-031A-4	No Description Available	1	piece
ACSM1-04AM-03A0-4	No Description Available	1	piece
ACSM1-04AM-040A-4	No Description Available	1	piece
ACSM1-04AM-046A-4	No Description Available	1	piece
ACSM1-04AM-04A0-4	No Description Available	1	piece
ACSM1-04AM-05A0-4	No Description Available	1	piece
ACSM1-04AM-060A-4	No Description Available	1	piece
ACSM1-04AM-073A-4	No Description Available	1	piece
ACSM1-04AM-07A0-4	No Description Available	1	piece
ACSM1-04AM-090A-4	No Description Available	1	piece
ACSM1-04AM-09A5-4	No Description Available	1	piece
ACSM1-04AM-110A-4	No Description Available	1	piece
ACSM1-04AM-135A-4	No Description Available	1	piece

ACSM1-04AM-135A-4 Identifier	No Description Available Description	1 Qty	piece Unit Of Measure
ACSM1-04AM-175A-4	No Description Available	1	piece
ACSM1-04AM-210A-4	No Description Available	1	piece
ACSM1-04AM-260A-4	No Description Available	1	piece
ACSM1-04AM-310A-4	No Description Available	1	piece
ACSM1-04AM-390A-4	No Description Available	1	piece
ACSM1-04AM-500A-4	No Description Available	1	piece
ACSM1-04AM-580A-4	No Description Available	1	piece
ACSM1-04AM-635A-4	No Description Available	1	piece
ACSM1-04AM-DEMOCASE-	No Description Available	1	piece
ACSM1-04AS-012A-4	No Description Available	1	piece
ACSM1-04AS-016A-4	No Description Available	1	piece
ACSM1-04AS-024A-4	No Description Available	1	piece
ACSM1-04AS-02A5-4	No Description Available	1	piece
ACSM1-04AS-031A-4	No Description Available	1	piece
ACSM1-04AS-03A0-4	No Description Available	1	piece
ACSM1-04AS-040A-4	No Description Available	1	piece
ACSM1-04AS-046A-4	No Description Available	1	piece
ACSM1-04AS-04A0-4	No Description Available	1	piece
ACSM1-04AS-05A0-4	No Description Available	1	piece
ACSM1-04AS-060A-4	No Description Available	1	piece
ACSM1-04AS-073A-4	No Description Available	1	piece
ACSM1-04AS-07A0-4	No Description Available	1	piece
ACSM1-04AS-090A-4	No Description Available	1	piece
ACSM1-04AS-09A5-4	No Description Available	1	piece
ACSM1-04AS-110A-4	No Description Available	1	piece
ACSM1-04AS-135A-4	No Description Available	1	piece
ACSM1-04AS-175A-4	No Description Available	1	piece
ACSM1-04AS-210A-4	No Description Available	1	piece
ACSM1-04AS-260A-4	No Description Available	1	piece
ACSM1-04AS-310A-4	No Description Available	1	piece
ACSM1-04AS-390A-4	No Description Available	1	piece
ACSM1-04AS-500A-4	No Description Available	1	piece
ACSM1-04AS-580A-4	No Description Available	1	piece
ACSM1-04AS-635A-4	No Description Available	1	piece
ACSM1-04AS-DEMOCASE-	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACSM1-04CL-024A-4	No Description Available	1	piece
ACSM1-04CL-031A-4	No Description Available	1	piece
ACSM1-04CL-040A-4	No Description Available	1	piece
ACSM1-04CL-046A-4	No Description Available	1	piece
ACSM1-04CL-060A-4	No Description Available	1	piece
ACSM1-04CL-073A-4	No Description Available	1	piece
ACSM1-04CL-090A-4	No Description Available	1	piece
ACSM1-04CM-024A-4	No Description Available	1	piece
ACSM1-04CM-031A-4	No Description Available	1	piece
ACSM1-04CM-040A-4	No Description Available	1	piece
ACSM1-04CM-046A-4	No Description Available	1	piece
ACSM1-04CM-060A-4	No Description Available	1	piece
ACSM1-04CM-073A-4	No Description Available	1	piece
ACSM1-04CM-090A-4	No Description Available	1	piece
ACSM1-04CS-024A-4	No Description Available	1	piece
ACSM1-04CS-031A-4	No Description Available	1	piece
ACSM1-04CS-040A-4	No Description Available	1	piece
ACSM1-04CS-046A-4	No Description Available	1	piece
ACSM1-04CS-060A-4	No Description Available	1	piece
ACSM1-04CS-073A-4	No Description Available	1	piece
ACSM1-04CS-090A-4	No Description Available	1	piece
ACSM1-04LM-110A-4	No Description Available	1	piece
ACSM1-04LM-135A-4	No Description Available	1	piece
ACSM1-04LM-175A-4	No Description Available	1	piece
ACSM1-04LM-210A-4	No Description Available	1	piece
ACSM1-04LS-110A-4	No Description Available	1	piece
ACSM1-04LS-135A-4	No Description Available	1	piece
ACSM1-04LS-175A-4	No Description Available	1	piece
ACSM1-04LS-210A-4	No Description Available	1	piece
ACSM1-04PL-024A-4	No Description Available	1	piece
ACSM1-04PL-031A-4	No Description Available	1	piece
ACSM1-04PL-040A-4	No Description Available	1	piece
ACSM1-04PL-046A-4	No Description Available	1	piece
ACSM1-04PL-060A-4	No Description Available	1	piece
ACSM1-04PL-073A-4	No Description Available	1	piece

Identifier	Description	Qty	Unit Of Measure
ACSM1-04PL-090A-4	No Description Available	1	piece
ACSM1-04PM-024A-4	No Description Available	1	piece
ACSM1-04PM-031A-4	No Description Available	1	piece
ACSM1-04PM-040A-4	No Description Available	1	piece
ACSM1-04PM-046A-4	No Description Available	1	piece
ACSM1-04PM-060A-4	No Description Available	1	piece
ACSM1-04PM-073A-4	No Description Available	1	piece
ACSM1-04PM-090A-4	No Description Available	1	piece
ACSM1-04PS-024A-4	No Description Available	1	piece
ACSM1-04PS-031A-4	No Description Available	1	piece
ACSM1-04PS-040A-4	No Description Available	1	piece
ACSM1-04PS-046A-4	No Description Available	1	piece
ACSM1-04PS-060A-4	No Description Available	1	piece
ACSM1-04PS-073A-4	No Description Available	1	piece
ACSM1-04PS-090A-4	No Description Available	1	piece

Where Used (as part of "kit")

Identifier	Description	Type
3AXD50000010345	3AXD50000010345 Kit	Kit

Product specific part data

Product	Category	Drive Part Category	Drive Section
ACS850-04-010A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-010A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-014A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-014A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-018A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-018A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-025A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-025A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-030A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-030A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category	Drive Section
ACS850-04-035A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-035A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-03A0-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-03A0-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-03A6-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-03A6-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-044A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-044A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-04A8-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-04A8-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-050A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-050A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-061A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-061A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-06A0-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-06A0-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-078A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-078A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-08A0-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-08A0-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-094A-2	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-094A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-103A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category	Drive Section
ACS850-04-144A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-166A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-202A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-225A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-260A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-290A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-430A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-521A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-602A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-693A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-720A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-DEMOCASE-	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-387A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-500A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-580A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-650A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-710A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-807A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS850-04-875A-5	ACS850-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-014A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-017A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-018A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-021A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category	Drive Section
ACS880-01-022A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-025A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-026A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-027A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-02A1-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-02A4-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-031A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-032A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-034A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-035A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-038A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-03A0-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-03A3-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-03A4-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-040A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-042A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-045A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-046A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-049A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-04A0-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-04A6-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-04A8-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-052A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category	Drive Section
ACS880-01-05A2-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-05A6-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-061A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-061A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-061A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-065A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-06A6-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-072A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-075A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-077A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-07A2-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-07A3-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-07A5-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-07A6-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-084A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-087A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-087A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-096A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-098A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-09A4-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-09A8-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-105A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-10A6-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	

Product	Category	etc.) Drive Part Category	Drive Section
ACS880-01-115A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-119A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-11A0-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-124A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-12A6-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-142A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-145A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-145A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-14A2-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-156A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-169A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-16A8-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-170A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-174A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-180A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-206A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-206A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-210A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-240A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-246A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-24A3-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-260A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-271A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O	

Product	Category	etc.) Drive Part Category	Drive Section
ACS880-01-274A-2	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-293A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-361A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-363A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-414A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-430A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-330A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-370A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-425A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-460A-5	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-470A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-503A-5	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-505A-3	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-522A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-583A-5	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-585A-3	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-590A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-635A-5	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-650A-3	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-650A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-715A-5	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-725A-3	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-820A-3	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O	

Product	Category	etc.) Drive Part Category	Drive Section
ACS880-04-820A-5	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-880A-3	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-02A5-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-03A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-04A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-05A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-07A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-09A5-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-012A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-016A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-024A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-110A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-135A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-175A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-210A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-390A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-500A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O	

Product	Category	Drive Part Category	Drive Section
ACSM1-04AS-580A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-635A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-02A5-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-03A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-04A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-05A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-07A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-09A5-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-012A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-016A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-024A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-110A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-135A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-175A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-210A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-390A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-500A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category	Drive Section
ACSM1-04AM-580A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-635A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-02A5-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-02A5-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-03A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-03A0-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-04A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-04A0-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-05A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-05A0-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-07A0-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-07A0-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-09A5-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-09A5-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-012A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-012A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-016A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-016A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-024A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-024A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-031A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Interface Option (Fieldbus, I/O etc.)	Drive Section
ACSM1-04AL-040A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-046A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-060A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-073A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-090A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-110A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-110A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-135A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-135A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-175A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-175A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-210A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AL-210A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CS-024A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CS-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CS-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CS-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CS-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CS-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	

ACSM1-04CS-073A-4 Product	ACSM1-04 - Machinery Drive Module Category	Interface Option (Fieldbus, I/O etc.) Drive Part Category	Drive Section
ACSM1-04CS-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CM-024A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CM-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CM-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CM-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CM-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CM-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CM-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-024A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-024A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-031A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-040A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-046A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-060A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-073A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CL-090A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04CS-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	

ACSM1-U4PS-U24A-4 Product	ACSM1-U4 - Machinery Drive Module Category	Interface Option (Fieldbus, I/O etc.) Drive Part Category	Drive Section
ACSM1-04PS-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PS-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PS-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PS-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PS-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PS-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PM-024A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PM-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PM-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PM-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PM-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PM-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PM-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-024A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-024A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-031A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-031A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-040A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-040A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-046A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-046A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-060A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	

ACSM1-04PL-060A-4 Product	ACSM1-04xL - elevator drive module Category	Interface Option (Fieldbus, I/O etc.) Drive Part Category	Drive Section
ACSM1-04PL-073A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-073A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-090A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04PL-090A-4	ACSM1-04xL - elevator drive module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04LS-110A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04LS-135A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04LS-175A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04LS-210A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04LM-110A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04LM-135A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04LM-175A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04LM-210A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS- DEMOCASE-	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM- DEMOCASE-	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-880A-5	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-430A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-04-721A-7	ACS880-04 - Single drive module	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-03A0-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-03A9-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-05A8-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-07A5-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-09A8-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category	Drive Section
ACS880-01-13A4-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-17A5-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-25A1-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-035A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-043A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-050A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-069A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-085A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-103A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-123A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-173A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-202A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-245A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-290A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-343A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-428A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-02A0-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-02A8-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-03A2-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-04A6-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-04A9-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-07A2-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-10A4-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category	Drive Section
ACS880-01-013A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-019A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-026A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-032A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-038A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-049A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-062A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-073A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-091A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-118A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-148A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-171A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-228A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-247A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-343A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-393A-4	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-010A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-14A5-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-20A2-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-24A8-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-29A0-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-39A9-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-47A5-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category (Fieldbus, I/O etc.)	Drive Section
ACS880-01-060A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-071A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-100A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-117A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-168A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-199A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-248A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-107-0470A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0640A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0760A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0900A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1250A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1480A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1760A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-2210A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-2610A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-3450A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-4290A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-5130A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0440A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0590A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0740A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0810A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)

Product	Category	Drive Pack Category	Drive Section
ACS880-107-1150A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1450A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1580A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-2150A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-2350A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-3110A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-3860A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-4610A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0340A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0410A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0530A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0600A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0800A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1030A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1170A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1540A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-1740A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-2300A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-2860A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-3420A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-3990A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-4560A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-5130A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)

Product	Category	Drive Part Category	Drive Section
ACS880-107-5700A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Drive Control Unit (DCU)
ACS880-107-0062A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0082A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0100A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0130A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0140A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0190A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0220A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0270A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0011A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0014A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0018A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0025A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0035A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0044A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-004A8-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0050A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0061A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-006A0-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0078A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-008A0-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0094A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0100A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)

Product	Category	Drive Part Category	Drive Section
ACS880-107-0140A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0170A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0210A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0250A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0300A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0350A-3	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0011A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0014A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0018A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0025A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0030A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0035A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-003A6-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-004A8-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0050A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0061A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-006A0-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0078A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-008A0-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0094A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0110A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0140A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0170A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)

Product	Category	Drive Part Category	Drive Section
ACS880-107-0200A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0240A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0300A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0340A-5	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0018A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0022A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0027A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0035A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0042A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-0052A-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-007A3-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-009A8-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-107-014A2-7	ACS880-107 - Inverter unit	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0990A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1140A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-0990A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1070A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-0330A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0370A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0800A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-0900A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-0950A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1160A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)

Product	Category	Drive Part Category	Drive Section
ACS880-07-0505A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0585A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0650A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0725A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0820A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0880A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0460A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0503A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0583A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0635A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0715A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0820A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0880A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0425A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0430A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0470A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0522A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0590A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0650A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0721A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-1250A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1480A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1760A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)

Product	Category	Drive Part Category	Drive Section
ACS880-07-2210A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-2610A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1320A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1450A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1580A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1800A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1980A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1450A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1650A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-1950A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-2300A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-2600A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-2860A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-07-0105A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0145A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0169A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0206A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0246A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0293A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0363A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0430A-3	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0096A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0124A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)

Product	Category	Drive Part Category	Drive Section
ACS880-07-0156A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0180A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0240A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0260A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0302A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0361A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0414A-5	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0061A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0084A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0098A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0119A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0142A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0174A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0210A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-07-0271A-7	ACS880-07 - Cabinet-built single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0450A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-17-0620A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-17-0870A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-17-1110A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-17-1210A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-17-1430A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-17-1700A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-17-2060A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)

[illegible]

[illegible]

Product	drive Category	etc.) Drive Part Category	(ACU) Drive Section
ACS880-37-1450A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-37-1680A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-37-1950A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-37-2230A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-37-2770A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACS880-37-3310A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Auxiliary Control Unit (ACU)
ACSM1-04AS-260A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AS-310A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-260A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACSM1-04AM-310A-4	ACSM1-04 - Machinery Drive Module	Interface Option (Fieldbus, I/O etc.)	
ACS880-17-0293A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0363A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0430A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0505A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0585A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0650A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0260A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0302A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0361A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0414A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0460A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0503A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0583A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)

Product	drive Category	Drive Part Category	Drive Section
ACS880-37-0293A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0363A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0430A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0505A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0585A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0650A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0260A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0302A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0361A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0414A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0460A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0503A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0583A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-01-442A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-441A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-427A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-364A-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-303A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-362A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-415A-5	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-504A-3	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-584A-3	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-649A-3	ACS880-04F	Interface Option (Fieldbus, I/O	

Product	Category	Drive Part Category	Drive Section
ACS880-04F-725A-3	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-820A-3	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-880A-3	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-459A-5	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-502A-5	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-582A-5	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-634A-5	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-715A-5	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-820A-5	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-880A-5	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-329A-7	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-369A-7	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-429A-7	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-470A-7	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-522A-7	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-590A-7	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-650A-7	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-04F-721A-7	ACS880-04F	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-03A0-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-03A6-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-04A8-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-06A0-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-08A0-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Interface Option (Fieldbus, I/O etc.)	Drive Section
ACS880-M04-04-010A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-014A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-018A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-025A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-030A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-035A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-044A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-050A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-061A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-078A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-094A-2	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-03A0-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-03A6-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-04A8-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-06A0-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-08A0-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-010A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-014A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-018A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-025A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-030A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-035A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-044A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	

Product	Category	Drive Part Category	Drive Section
ACS880-M04-04-050A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-061A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-078A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-M04-04-094A-5	ACS880-M04 - Machinery Drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-37-0105A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0145A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0169A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0206A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0442A-3	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0101A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0124A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0156A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0180A-5	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0174A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0210A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0271A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0330A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0370A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-37-0430A-7	ACS880-37 - Cabinet-built low harmonic single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0105A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0145A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0169A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0206A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)

ACS880-17-0206A-3 Product	ACS880-17 - Cabinet-built regenerative single drive Category	Interface Option (Fieldbus, I/O etc.) Drive Part Category	Inverter Unit (INU) Drive Section
ACS880-17-0442A-3	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0101A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0124A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0156A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0180A-5	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0174A-7	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0210A-7	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0271A-7	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0330A-7	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0370A-7	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-17-0430A-7	ACS880-17 - Cabinet-built regenerative single drive	Interface Option (Fieldbus, I/O etc.)	Inverter Unit (INU)
ACS880-01-14A3-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-17A7-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-25A5-3	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-143A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-07A4-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-09A9-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-14A3-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-019A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-023A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	
ACS880-01-027A-7	ACS880-01 - Wall-mounted single drive	Interface Option (Fieldbus, I/O etc.)	

