

**131F6617** [↗](#)**FC-302P22KT5E20H1BGXXXXXXXAXBXXXXDX**

FC-302P22KT5E20H1BGXXXXXXXAXBXXXXDX

Frequency converter

FC-302P22KT5E20H1BGXXXXXXXAXBXXXXDX

VLT® AutomationDrive FC-302

(P22K) 22 KW / 30 HP, Three phase

380 - 500 VAC, (E20) IP20 / Chassis

(H1) RFI Class A1/B (C1)

Brake chopper

Graphical Loc. Cont. Panel

Not coated PCB, No Mains Option

Latest release std. SW.

No A Option, No B Option

No C1 option, No D option

Frame: B4

Other options according to Model code

Model code: FC-302P22KT5E20H1BGXXXXXXXAXBXXXXDX

The VLT® AutomationDrive represents a single drive concept that controls the entire range of operations from ordinary to servo like applications on any machine or production line.

View Efficiency Data [↗](#)**PRODUCT DETAILS**

Gross weight		21.72 kg
Net weight		20.65 kg
Volume		144.67 l
EAN		5702427465121
Sales restriction control		
Matr grp for sales restriction	0001	No grouping
VLT® AUTOMATIONDRIVE FC 300 SERIES		
Product View (Switch)	GLBL	Global (Standard)
Product Group	FC-	VLT® AutomationDrive FC-
Series	302	302
Power Rating	P22K	(P22K) 22 KW / 30 HP
Phase	T	Three phase
Mains Voltage	5	380 - 500 VAC
Enclosure	E20	(E20) IP20 / Chassis
RFI Filter	H1	(H1) RFI Class A1/B (C1)
Brake - Safe Stop	B	Brake chopper
LCP	G	Graphical Loc. Cont. Panel
Coating PCB	X	Not coated PCB
Mains Option	X	No Mains Option
Adaptation A	X	Standard Cable Entries
Adaptation B	X	No adaptation
Software Release	SXXX	Latest release std. SW.
Software Language Pack	X	Standard Language Pack

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

PRODUCT DETAILS

A Option	AX	No A Option
B Option	BX	No B Option
C0 Option MCO	CX	No C0 option
C1 Option	X	No C1 option
C Option Software	XX	No software option
D Option	DX	No D option
Frame Size	B4	B4
Typecode Part 1		FC-302P22KT5E20H1BGX
Typecode Part 2		XXXXXXXXAXBXCXXXXX
Product Catalog	NO_VIEW	NO VIEW
Power 180% (HO) [KW]		NV
Power 160% (HO) [KW]		22
Power 150% (HO) [KW]		NV
Power 110% (NO) [KW]		30
Height [mm]		520,0
Height w/ Regen/Loadshare [mm]		NV
Width w/ no C options [mm]		230,0
Depth [mm]		242,0
Depth with Option A/B [mm]		242,0
kVA		30.5
Power Loss NO [W]		739
Power Loss NO [W]		739
Power Loss HO [W]		547
Power Loss HO [W]		547
Continuous Current (NO) [A]		61
Intermittent Current (NO) [A]		67.1
Continuous Current (NO) [A]		52
Intermittent Current (NO) [A]		57.2
Continuous Current (HO) [A]		44
Intermittent Current (HO) [A]		70.4
Continuous Current (HO) [A]		40
Intermittent Current (HO) [A]		64
Calculated Gross Weight		20.8
Calculated Net Weight [kg]		20.5
Material Gross Weight		21.72
Material Net Weight		20.65
Vendor	ERR01	Cannot Determine Vendor
Modelcode01		FC-302P22KT5E20H1BGX
Modelcode02		XXXXXXXXAXBXCXXXXX

For Documents, Software, Visuals and more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

Image
coming
soon

130B3290 [🔗](#)

VLT® Safe option MCB 151, coated

VLT® Safe option MCB 151, painted for HTL feedback, can be used up to PL d or SIL 2



130B3280 [🔗](#)

VLT® Safe option MCB 150, coated

Safety modules enable machines to interact intelligently with operators to increase safety, reduce system costs, improve flexibility and increase productivity.

VLT® MCB 15x Safe options provide an intelligent, user-friendly solution to meet the IEC 61800-5-2 functional safety standard and helps to reduce cabling.

The new safety module is certified according to ISO 13849-1 PL d Category 3 and SIL 2 according to IEC 61508.



130B4172 [🔗](#)

Back plate IP20/Chassis, B4

Back plate IP20/Type 1, enclosure size B4



130B7533 [🔗](#)

Mounting Kit C Option, B/C/D/E/F(not B3)

MCF105 C Option, Mounting Kit A2 and A3



130B7635 [🔗](#)

VLT® Lift Controller MCO 361

VLT® Motion Control MCO 305 with special software for lift application



130B7145 [🔗](#)

VLT® SALT Controller MCO 360



130B6443 [🔗](#)

VLT® Safety Option MCB 140

Extends the Safe Torque Off feature of VLT® drives with additional safety functions: Safe Stop 1 (SS1), Safely Limited Speed (SLS), Safe Maximum Speed (SMS) and Safe Speed Monitor (SSM).

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

Image coming soon

130B9860

VLT® Safety Option MCB152, coated

Safety modules enable machines to interact intelligently with operators to increase safety, reduce system costs, improve flexibility and increase productivity.

VLT® Safety Option MCB152 provides an intelligent, user-friendly solution to meet the IEC 61800-5-2 functional safety standard and helps to reduce cabling. MCB152 enables activation of the Safe Torque Off (STO) irrespective of where a hazard occurs.

The new safety module is certified according to ISO 13849-1 PL d Category 3 and SIL 2 according to EN IEC 61508.

The combination of VLT® Safety Option MCB152, PROFINET fieldbus option MCA120, and the control card of the VLT® AutomationDrive constitutes a PROFIsafe device.



130B5765

Leakage Current Monitor Kit, B4



130B5646

VLT® EtherCAT MCA 124, coated

MCA 124 Ethercat option painted The VLT® EtherCat MCA 124 option enables Connection to EtherCat-based networks via the EtherCat protocol.

The option allows an EtherCat connection with full Speed and a connection to the frequency converter with a time interval of 4 ms in both Directions. This enables the MCA124 to be used in Networks from low-power applications to Servo applications.

- EoE EtherNet over EtherCat support
- HTTP (Hypertext Transfer Protocol) for diagnosis via integrated web server
- SMTP (Single Mail Transfer Protocol) for email notification
- TCP / IP for easy access to frequency converters Configuration data via MCT 10



130B5436

Side Fixture Mounting Kit

Side Fixture Mounting Kit for enclosure size A5 / B1 / B2 / C1 / C2

To be used when retrofitting the following MCA options:

- MCA 120 Profinet
- MCA 121 EtherNet
- MCA 122 Modbus TCP
- MCA 123 POWERLINK
- MCA 124 EtherCAT
- Product group: R1



130B5435

DIN Rail Mounting Kit

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1235** [🔗](#)**VLT® PROFINET MCA 120, coated**

MCA 120 PROFINET interface

With reinforced coating (class 3C3 / IEC 60721-3-3)

- Supports operation on PROFINET network with extensive characteristics
- DCP support for easy setting u. Communication parameters via the PLC
- on Board web-Page with Drive Status
- parameterization with the MCT10 software
- 2-port version, reduced external hardware

**130B1234** [🔗](#)**VLT® Motion Control MCO 305, coated**

Integrated and programmable motion controller for VLT® AutomationDrive FC 301 and FC 302

- Adds additional functionality and flexibility as it is a freely programmable module
- Optimized for all types of positioning and synchronization applications
- Make your own program specially adapted to your application

Contains:

- synchronization (electronic shaft), positioning and electronic cam control
- 2 inputs support both stepwise and absolute encoders
- 1 encoder output (virtual master function)

10 digital inputs

- 8 digital outputs

- Sends and receives data via fieldbus interface (requires fieldbus option)

- PC software for programming and commissioning

Remember to order the Mounting kit if the above MCO option is required retrofitted.

130B7530 - Mounting kit for enclosures A2 and A3

130B7531 - Mounting kit for MCO Option, together with MCB 113, in enclosures A2 and A3

130B1413 - Mounting kit for enclosure B3

130B1414 - Mounting kit for MCO Option, together with MCB 113, in enclosure B3

130B7532 - Mounting kit for enclosure A5

130B7533 - Mounting kit for all enclosures B, C, D, E and F (B3 excepted)

Danfoss MCO options are not sold without prior advice.

Danfoss can offer help with programming / setting up MCO options.

Contact Danfoss for advice and prices.

Product group: R

**130B1245** [🔗](#)**VLT® PROFIBUS Converter MCA 113, ctd**

Ensures easy and quick replacement of VLT®3000 to VLT® AutomationDrive

VLT® 3000 can then be replaced by VLT® AutomationDrive or

- the system Can be expanded without costly changes to the PLC program
- Flexible investment as it is easy to remove and replace option when upgrading to another fieldbus

Product group: R1

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1227** [🔗](#)**VLT® Resolver Input MCB 103, coated**

Resolver extension for FC 300. Enables the connection of the following

Resolver types:

Input voltage: 4..8 Vrms

Input frequency: 2.5..15 kHz

Number of resolver poles: 2 or 4

**130B1220** [🔗](#)**VLT® Safe PLC I/O MCB 108, coated**

Increases security and helps you meet requirement security levels

- VLT® AutomationDrive FC 302 has a safety input based on a

single pole 24 V DC input

- Security in a cost-effective way

Possibility of connection to two conductor safety system

Possibility to interrupt on the plus or minus side without disturbing the sensor signal

**130B1219** [🔗](#)**VLT® EtherNet IP MCA 121, coated**

EtherNet/IP extends commercial off-the-shelf Ethernet to the Common Industrial Protocol (CIP™) – the same upper-layer protocol and object model found in DeviceNet. Built-in high-performance switch enabling line-topology, and eliminating the need for external switches. Device Level Ring (DLR) topology for higher system availability. Based on CIP™, makes the reuse of PLC program possible when migrating from DeviceNet to EtherNet/IP. Built-in web server provides remote diagnosis and reading out of basic drive parameters. E-mail notification provides fast access to warnings or alarm information. Unicast and Multicast communication for improved network utilization. Certified by ODVA for fulfilment of the newest standard.

**130B1264** [🔗](#)**VLT® Extended Relay Card MCB 113, ctd**

Adds 7 digital inputs and 2 analog outputs for increased flexibility. 4

SPDT relays. Meets NAMUR recommendations. Galvanic isolation capability.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1253****VLT® Position Controller MCO 351, ctd**

Extends the functional characteristics of the frequency converter in positioning applications

- Direct positioning via fieldbus, relative positioning, absolute positioning and touch probe positioning
- End stop handling (software and hardware)
- Mechanical brake handling (programmable hold delay)

Error handling

- Jog speed / manual operation
- None for programming, as it is pre-programmed

Remember to order the Mounting kit if the above MCO option is required retrofitted.

130B7530 - Mounting kit for enclosures A2 and A3

130B7531 - Mounting kit for MCO Option, together with MCB 113, in enclosures A2 and A3

130B1413 - Mounting kit for enclosure B3

130B1414 - Mounting kit for MCO Option, together with MCB 113, in enclosure B3

130B7532 - Mounting kit for enclosure A5

130B7533 - Mounting kit for all enclosures B, C, D, E and F (B3 excepted)

Danfoss MCO options are not sold without prior advice.

Danfoss can offer help with programming / setting up MCO options.

Contact Danfoss for advice and prices.

Product group: R

**130B1252****VLT® Synchronizing Ctrl. MCO 350, ctd**

MCO 350 - synchronous controller

Based on the MCO 305 prefabricated controller for Synchronization tasks. The adjustment takes place through parameter settings. Specific Programming skills are not required.

- 2 encoder inputs, both for incremental as well as absolute encoder
 - 1 encoder output (virtual master function)
 - 10 additional digital inputs
 - 8 additional digital outputs
 - fieldbus Communication (requires fieldbus card) with reinforced coating
-

**130B1246****VLT® PROFIBUS Converter MCA 114, ctd**

A special version of the PROFIBUS options that emulates VLT® 5000 commands in the VLT® AutomationDrive. The VLT® 5000 can be replaced by the VLT® AutomationDrive, or an existing system can be expanded without costly change of the PLC program. For upgrade to a different fieldbus, the installed converter is easily removed and replaced with a new option. This secures the investment without losing flexibility. The option supports DPV1.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1196** [🔗](#)**VLT® Modbus TCP MCA 122**

MCA 122 Modbus TCP interface Complex compatibility tests make the perfect operation in Modbus TCP systems for sure.

- On Board web-Page with Drive Status
- Parameterization with MCT10 software
- 2 port version reduces effort for external hardware (switch, cables, etc.) and allows flexible bus topologies

**130B1190** [🔗](#)**IP21 conversion kit, top, B4**

IP21 top cover for enclosure B4

Product group: R1

**130B1189** [🔗](#)**IP21 conversion kit for B4 frame.**

IP21 cover for enclosure B4

Product group: R1

**130B1172** [🔗](#)**VLT® Sensor Input Card MCB 114, unctd**

Protects the motor from being overheated by monitoring the temperature of bearings and windings in the motor. Three self-detecting sensor inputs for 2 or 3 wire PT100/PT1000 sensors. One additional analog input 4–20 mA.

**130B1170** [🔗](#)**LCP Panel Mounting Kit**

The kit includes fasteners and gasket. No LCP and no cable included.

**130B1212** [🔗](#)**VLT® General Purpose I/O MCB 101, ctd**

MCB 101 - Advanced I / O option

Expands the number of freely programmable

Control inputs and outputs around the following I / Os:

- 3 digital inputs opto-decoupled 0 - 24 V.
 - 2 analog inputs 0 - 10 V.
 - 2 digital outputs NPN / PNP switchable 24 V
 - 1 analog output 0/4 - 20 mA
- with reinforced coating

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1210** [🔗](#)**VLT® Relay Option MCB 105, coated**

Relay extension for FC 100 and FC 300.

Extension with 3 additional load relays (changeover contacts), easy to retrofit thanks to modular technology.

Painted version for harsh environments,

easy to retrofit thanks to modular technology.

Max. Load 240V AC (resistive): 2 A

Max. Load 240V AC (Cos Phi 0.4): 0.2 A

Max. Load 24V DC (ohmic): 1 A

Max. Load 24V DC (inductive): 0.1 A

**130B1208** [🔗](#)**VLT® 24V DC Supply MCB 107, coated**

Connect an external DC supply to keep the control section and any installed option alive during power failure. Enables full operation of the LCP (including the parameter setting) and all installed options without connection to mains.

**130B1205** [🔗](#)**VLT® CAN Open MCA 105, coated**

CANopen interface for FC 300. Max. Baud rate 500 kBit / s. Support that DSP402 drive profile and PDO / SDO communication. Painted version for harsh environments. Easy to retrofit thanks to modular technology.

**130B1203** [🔗](#)**VLT® Encoder Input MCB 102, coated**

Offers the possibility to connect various types of incremental and absolute encoders. The connected encoder can be used for closed-loop speed control as well as closed-loop flux motor control.

**130B1202** [🔗](#)**VLT® DeviceNet MCA 104, coated**

MCA 104 - DeviceNet interface Option for FC300 and FC100 for mounting on the control card. Painted version

**130B1200** [🔗](#)**VLT® Profibus DP V1 MCA 101, coated**

Provides wide compatibility, a high level of availability, support for all major PLC vendors and compatibility with future versions. Fast, efficient communication, transparent installation, advanced diagnosis and parameterization and auto-configuration of process data using GSD-file. Acyclic parameterization using PROFIBUS DP-V1, -PROFIdrive or Danfoss FC profile state machines, PROFIBUS DP-V1, Master Class 1 and 2.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B1387 [🔗](#)
opt.control,24v, multipack 5 pcs.



130B1386 [🔗](#)
VLT® Profibus DP V1 MCA 101, ctd, 5pcs



130B1385 [🔗](#)
VLT® Profibus DP V1 MCA101, unctd 5pcs



130B1272 [🔗](#)
VLT® Sensor Input Card MCB 114, coated
MCB 114 - PT100 / PT1000 option
For FC100-FC200 and FC302 (painted version)
Enables the evaluation of up to 3 PT 100 or 3 PT 1000 sensors
- Connection of 2 and 3 wire sensors
- Automatic detection of the sensor type
- Additional 4-20mA input



130B1296 [🔗](#)
VLT® Modbus TCP MCA 122, coated
The first industrial Ethernet-based protocol for automation. Connects to Modbus-TCP-based networks. Able to handle connection interval down to 5 ms in both directions, positioning it among the fastest performing Modbus TCP devices in the market. For master redundancy it features hot swapping between two masters.



130B1164 [🔗](#)
VLT® Extended Relay Card MCB 113
Adds 7 digital inputs and 2 analog outputs for increased flexibility. 4 SPDT relays. Meets NAMUR recommendations. Galvanic isolation capability.



130B1006 [🔗](#)
VLT® Motion Ctrl Tool MCT 10>100 lic.
An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1005** [🔗](#)**VLT® Motion Ctrl Tool MCT 10,100 lic.**

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.

**130B1004** [🔗](#)**VLT® Motion Ctrl Tool MCT 10,50 lic.**

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.

**130B1003** [🔗](#)**VLT® Motion Ctrl Tool MCT 10,25 lic.**

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.

**130B1002** [🔗](#)**VLT® Motion Ctrl Tool MCT 10,10 lic.**

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.

**130B1001** [🔗](#)**VLT® Motion Ctrl Tool MCT 10,5 lic.**

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B1000 [🔗](#)

VLT® Motion Ctrl Tool MCT 10,1 lic.

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.



130B1135 [🔗](#)

VLT® PROFINET MCA 120, UNCOATED

MCA 120 PROFINET interface

- Supports operation on PROFINET network with extensive properties
- DCP support for easy setting u. Communication parameters via the PLC
- On Board web-Page with Drive Status
- Parameterization with the MCT10 software
- 2 port version, reduced external hardware



130B1134 [🔗](#)

VLT® Motion Control MCO 305, uncoated

Integrated and programmable motion controller for VLT® AutomationDrive FC 301 and FC 302

- Adds additional functionality and flexibility as it is a freely programmable module
- Optimized for all types of positioning and synchronization applications
- Make your own program specially adapted to your application

Contains:

- synchronization (electronic shaft), positioning and electronic cam control
- 2 inputs support both stepwise and absolute encoders
- 1 encoder output (virtual master function)

10 digital inputs

8 digital outputs

- Sends and receives data via fieldbus interface (requires fieldbus Option)
- PC software for programming and commissioning.

Remember to order the Mounting kit if the above MCO option is required retrofitted.

130B7530 - Mounting kit for enclosures A2 and A3

130B7531 - Mounting kit for MCO Option, together with MCB 113, in enclosures A2 and A3.

130B1413 - Mounting kit for enclosure B3

130B1414 - Mounting kit for MCO Option, together with MCB 113, in enclosure B3

130B7532 - Mounting kit for enclosure A5

130B7533 - Mounting kit for all enclosures B, C, D, E and F (B3 excepted)

Danfoss MCO options are not sold without prior advice. Danfoss can offer help with programming / setting up MCO options. Contact Danfoss for advice and prices.

Product group: R



130B1127 [🔗](#)

VLT® Resolver Input MCB 103, uncoated

Enables connection of a resolver to provide speed feedback from the motor. Spring loaded connection.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1125** [🔗](#)**VLT® General Purpose I/O MCB 101, unctd**

MCB 101 - Advanced I / O option

Expands the number of freely programmable Control inputs and outputs around the following I / Os:

- 3 digital inputs opto-decoupled 0 - 24 V.
- 2 analog inputs 0 - 10 V.
- 2 digital outputs NPN / PNP switchable 24 V
- 1 analog output 0/4 - 20 mA

**130B1124** [🔗](#)**VLT® Control Panel LCP 101, numeric**

Numerical control unit for FC 100 and FC 300. Allows access to all device parameters.

Quick menu for brief commissioning. Manual / auto switchover and alarm acknowledgment.

**130B1120** [🔗](#)**VLT® Safe PLC I/O MCB 108, uncoated**

Connection converter for FC 300 with control input for a safe stop. Allows secure connection.

Output modules with diagnostic pulse (Cross-circuit monitoring).

**130B1119** [🔗](#)**VLT® EtherNet/IP MCA 121, uncoated**

MCA 121 EtherNet / IP interface

- Allows connection to EtherNet / IP based Automation systems via CIP (CommonInterface Protocol)
- 2 port design reduces external components
- HTTP for diagnosis via built-in web server
- SMTP, DHCP and FTP protocols
- Prepared for parameterization with the MCT 10 software via TCP / IP
- Certified according to ODVA

**130B1117** [🔗](#)**LCP Mounting Kit, w/ no LCP**

The kit includes fasteners, 3m cable and gasket - There is no LCP included.

**130B1115** [🔗](#)**VLT® Encoder Input MCB 102, uncoated**

Offers the possibility to connect various types of incremental and absolute encoders. The connected encoder can be used for closed-loop speed control as well as closed-loop flux motor control.

**130B1114** [🔗](#)**LCP Mounting Kit w/ numerical LCP101, 3m**

The kit includes numerical LCP, fasteners, 3m cable and gasket.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1113** [🔗](#)**lcp panel kit/fc300 fg-lcp panel kit**

The kit includes graphical LCP, fasteners, 3m cable and gasket.

**130B1110** [🔗](#)**VLT® Relay Option MCB 105, uncoated**

Relay extension for FC 100 and FC 300. Extension with 3 additional load relays (changeover contacts), easy to retrofit thanks to modular technology.

Max. Load 240V AC (resistive): 2 A

Max. Load 240V AC (Cos Phi 0.4): 0.2 A

Max. Load 24V DC (ohmic): 1 A

Max. Load 24V DC (inductive): 0.1 A

**130B1153** [🔗](#)**VLT® Position Controller MCO351, unctd**

Extends the functional characteristics of the frequency converter in positioning applications

- Direct positioning via fieldbus, relative positioning, absolute positioning and touch probe positioning
- End stop handling (software and hardware)
- Mechanical brake handling (programmable hold delay)

Error handling

- Jog speed / manual operation
- None for programming, as it is pre-programmed

Remember to order the Mounting kit if the above MCO option is required retrofitted.

130B7530 - Mounting kit for enclosures A2 and A3

130B7531 - Mounting kit for MCO Option, together with MCB 113, in enclosures A2 and A3

130B1413 - Mounting kit for enclosure B3

130B1414 - Mounting kit for MCO Option, together with MCB 113, in enclosure B3

130B7532 - Mounting kit for enclosure A5

130B7533 - Mounting kit for all enclosures B, C, D, E and F (B3 excepted)

Danfoss MCO options are not sold without prior advice. Danfoss can offer help with programming / setting up MCO options. Contact Danfoss for advice and prices.

Product group: R

**130B1152** [🔗](#)**VLT® Synchronizing Contr. MCO350, unctd**

Expands the functional properties of the VLT® AutomationDrive in synchronizing applications, and replaces traditional mechanical solutions. Speed synchronizing. Position (angle) synchronizing with or without marker correction. Online adjustable gear ratio. Online adjustable position (angle) offset. Encoder output with virtual master function for synchronization of multiple followers. Control via I/Os or fieldbus. Home function. Configuration as well as read-out of status and data via the Local Control Panel of the drive.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

**130B1137** [🔗](#)**VLT® PTC Thermistor Card MCB 112, ctd**

MCB 112 PTC - thermistor relay MS220DA In connection with ATEX certified explosion-proof motors for full motor protection. Certified PTC sensors are the sole protection required.

Integrable module with ATEX-compliant full thermal motor protection

1 PTB-certified PTC thermistor input

1 switch-off signal for using the Safe Stop function

1 logic output for error identification

**130B1077** [🔗](#)**Blindcover, w/ Danfoss logo, IP55/66**

LCP Blindcover IP66

**130B1071** [🔗](#)**6 Pole Connector, FC series, 10 pcs**

6-pole spring cage connectors 10 pcs

**130B1070** [🔗](#)**RS485 plug, FC series, 10 pcs**

10pcs RS485 connectors for FC-series.

Product group: R

**130B1108** [🔗](#)**VLT® 24V DC Supply MCB 107, uncoated**

Connect an external DC supply to keep the control section and any installed option alive during power failure. Enables full operation of the LCP (including the parameter setting) and all installed options without connection to mains.

**130B1107** [🔗](#)**VLT® Control Panel LCP 102**

Graphic operating unit LCP102 Illuminated graphic display with plain text. Supports all languages and characters. Quick menu for brief commissioning. Saving and copying parameter sets. Online help for each function

**130B1103** [🔗](#)**VLT® CAN Open MCA 105, uncoated**

Standardized handling and interoperability for high flexibility and low costs. Fully equipped with both high-priority access to control and status of the drive (PDO Communication) and access to all parameters through acyclic data (SDO Communication). For interoperability the option has implemented the DSP402 AC-drive profile.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B1102 [🔗](#)

VLT® DeviceNet MCA 104, uncoated

Robust, efficient data handling thanks to advanced Producer/Consumer technology. ODVA's strong conformance testing policies ensure products are interoperable, and the AC-drive profile, supported using I/O instance 20/70.21/71, secures compatibility to existing systems.



130B1100 [🔗](#)

VLT® Profibus DP V1 MCA 101

Provides wide compatibility, a high level of availability, support for all major PLC vendors and compatibility with future versions. Fast, efficient communication, transparent installation, advanced diagnosis and parameterization and auto-configuration of process data using GSD-file. Acyclic parameterization using PROFIBUS DP-V1, -PROFIdrive or Danfoss FC profile state machines, PROFIBUS DP-V1, Master Class 1 and 2.



130B1088 [🔗](#)

LCP Blindcover, w/ Danfoss logo, IP20/21



130B1490 [🔗](#)

VLT® POWERLINK MCA 123, coated

Represents the second generation of fieldbus. The high bit rate of industrial Ethernet can now be used to make the full power of IT technologies used in the automation world available for the factory world.

Image
coming
soon

134B6302 [🔗](#)

VLT MCT 10 Software Customizer, 1 key

the commissioning experience of the VLT® to best fit your needs. It is a strong tool that enables you to quickly create your setup and test it first to MCT 10 using the simulator before uploading it to a real drive. local Danfoss Drives representative to order the required license(s).

Customize your commissioning experience

As the name suggests, VLT® Software Customizer allows you to customize

Note that the Advanced MCT 10 license is needed, please contact the

Image
coming
soon

130B6447 [🔗](#)

VLT® Safety Option MCB 141

Extends the Safe Torque Off feature of VLT® drives with additional safety functions: Safe Stop 1 (SS1), Safely Limited Speed (SLS), Safe Maximum Speed (SMS) and Safe Speed Monitor (SSM).



130B1266 [🔗](#)

VLT MCB 115 Programmable I/O, coated

VLT® MCB 115 programmable I / O, coated

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B0295 [🔗](#)
Accessory bag with control card plugs

Image
coming
soon

130B4847 [🔗](#)
extension cable for lcp+communication



134B8814 [🔗](#)
VLT® PROFINET MCA120 coated 5pcs



134B8492 [🔗](#)
Transducer 0-10g, 4-20mA; HS-22B50



134B8493 [🔗](#)
CBM Transducer 0-25mm/s RMS 4-20mA



134B8494 [🔗](#)
Transducer w, temp 0-25mm/s RMS 4-20mA



134B8496 [🔗](#)
Cable assy 10m, straight socket connetc.

Image
coming
soon

134B8497 [🔗](#)
Cable assy, M12 female connec.10m screen

Spare Parts



130B7530 [🔗](#)
Mounting Kit f. C Option, 40mm, A2/A3
MCF 105 assembly kit A2 / A3 for C option

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



130B9005 [🔗](#)
Plastic busbar for frame B4, H6



x10

130B9001 [🔗](#)
multiple 2 pole power combicon, 24V plug



130B5601 [🔗](#)
VLT® DeviceNet converter MCA194 coated
VLT® DeviceNet converter MCA194 coated



130B0295 [🔗](#)
Accessory bag with control card plugs



130B1069 [🔗](#)
Multiple relay 1 plug
spare, 3 pole connector, relay 1, fc300



130B1068 [🔗](#)
Multiple relay 2 plug
spare, 3 pole connector, relay 2, fc300



130B1107 [🔗](#)
VLT® Control Panel LCP 102
Graphic operating unit LCP102 Illuminated graphic display with plain text. Supports all languages and characters. Quick menu for brief commissioning. Saving and copying parameter sets. Online help for each function



130B1088 [🔗](#)
LCP Blindcover, w/ Danfoss logo, IP20/21



130B1955 [🔗](#)
DC Link Card 30+37kW 400/500V



130B1944 [🔗](#)
Power Card 30kW 500V
If the drive is build before April 1th 2013 replacement of the power card is not possible and the whole drive will have to be replaced.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



130B1435 [🔗](#)
DC coil 30kW T4/6 and 15kW T2



130B1416 [🔗](#)
RFI unit 200/500V adv. A1/B frame B4



134B8963 [🔗](#)
Heatsink B4 machined

Services



131H3620 [🔗](#)
FC-302P30KT5E20H1BGCDXXXXXXXAXBXXXXX
Frequency converter
FC-302P30KT5E20H1BGCDXXXXXXXAXBXXXXX
VLT® AutomationDrive FC-302
(P30K) 30 KW / 40 HP, Three phase
380 - 500 VAC, (E20) IP20 / Chassis
(H1) RFI Class A1/B (C1)
Brake chopper
Graphical Loc. Cont. Panel
Coated PCB, Loadsharing
Latest release std. SW.
No A Option, No B Option
No C1 option, No D option
Frame: B4
Other options according to Model code

Model code: FC-302P30KT5E20H1BGCDXXXXXXXAXBXXXXX

The VLT® AutomationDrive represents a single drive concept that controls the entire range of operations from ordinary to servo like applications on any machine or production line.



130R1131 [🔗](#)
DrivePro ExWarr Work Shop PG04 30 months
DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1134** [🔗](#)**DrivePro ExWarr Work Shop PG04 48 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1135** [🔗](#)**DrivePro ExWarr Work Shop PG04 54 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1137** [🔗](#)**DrivePro ExWarr Work Shop PG04 66 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1138** [🔗](#)**DrivePro ExWarr Work Shop PG04 72 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1136** [🔗](#)**DrivePro ExWarr Work Shop PG04 60 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1130** [🔗](#)**DrivePro ExWarr Work Shop PG04 24 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1132** [🔗](#)**DrivePro ExWarr Work Shop PG04 36 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1133** [🔗](#)**DrivePro ExWarr Work Shop PG04 42 months**

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1034** [🔗](#)**DrivePro ExWarr Onsite PG04 48 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1031** [🔗](#)**DrivePro ExWarr Onsite PG04 30 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1032** [🔗](#)**DrivePro ExWarr Onsite PG04 36 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

**130R1035** [🔗](#)**DrivePro ExWarr Onsite PG04 54 months**

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services



130R1033 [🔗](#)

DrivePro ExWarr Onsite PG04 42 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1030 [🔗](#)

DrivePro ExWarr Onsite PG04 24 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1038 [🔗](#)

DrivePro ExWarr Onsite PG04 72 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1036 [🔗](#)

DrivePro ExWarr Onsite PG04 60 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1037 [🔗](#)

DrivePro ExWarr Onsite PG04 66 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.

You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store [🔗](#)

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services



DrivePro® Start-up

130R1303**DrivePro Start-Up unit pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.



DrivePro® Start-up

130R1324**DrivePro SU + ctr interface test A,B & C**

DrivePro Start-Up Control interface testing small frame unit



DrivePro® Start-up

130R1321**DrivePro SU + spec. applications A,B & C**

DrivePro Start-Up special applications small frame unit



DrivePro® Start-up

130R1313**DrivePro Start-Up 1 day on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

**130R1312****DrivePro Start-Up 1 Day Pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

**130R1304****DrivePro Start-Up unit on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

Image
coming
soon**130R1380** **DrivePro Start-Up ½ day pre-order small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

General Terms and Conditions of Delivery and Warranty apply.

Image
coming
soon**130R1381** **DrivePro Start-up ½ day on-demand small**

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.

The following benefits can be gained:

- Installation is checked to ensure it complies to Danfoss guide lines.
- The AC drive is fine-tuned specific to the application, ensuring optimal performance.
- Maximum energy savings to the Customer.
- Extend the AC drive's lifespan.
- Report detailing findings.

Before DrivePro® Start-up can be implemented, the AC drive must be installed and

ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

General Terms and Conditions of Delivery and Warranty apply.

For more information, please use this link to visit the product page on Danfoss Product Store 

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.